





Pushbuttons with Plastic Bezel


Style	Operation	Contact	Type No.	① Button Color Code	
<b>Flush</b> 	Momentary	1NO	YW1B-M1E10①	B: black G: green R: red S: blue W: white Y: yellow	
		1NC	YW1B-M1E01①		
		2NO	YW1B-M1E20①		
		2NC	YW1B-M1E02①		
		1NO-1NC	YW1B-M1E11①		
		3NO	YW1B-M1E30①		
		3NC	YW1B-M1E03①		
		2NO-1NC	YW1B-M1E21①		
	1NO-2NC	YW1B-M1E12①			
	Maintained	1NO	YW1B-A1E10①		
		1NC	YW1B-A1E01①		
		2NO	YW1B-A1E20①		
		2NC	YW1B-A1E02①		
		1NO-1NC	YW1B-A1E11①		
<b>Extended</b> 	Momentary	1NO	YW1B-M2E10①	B: black G: green R: red S: blue W: white Y: yellow	
		1NC	YW1B-M2E01①		
		2NO	YW1B-M2E20①		
		2NC	YW1B-M2E02①		
		1NO-1NC	YW1B-M2E11①		
	Maintained	1NO	YW1B-A2E10①		
		1NC	YW1B-A2E01①		
		2NO	YW1B-A2E20①		
		2NC	YW1B-A2E02①		
		1NO-1NC	YW1B-A2E11①		
<b>Mushroom ø40mm</b> 	Momentary	1NO	YW1B-M4E10①	B: black G: green R: red S: blue W: white Y: yellow	
		1NC	YW1B-M4E01①		
		2NO	YW1B-M4E20①		
		2NC	YW1B-M4E02①		
		1NO-1NC	YW1B-M4E11①		
	Maintained	1NO	YW1B-A4E10①		
		1NC	YW1B-A4E01①		
		2NO	YW1B-A4E20①		
		2NC	YW1B-A4E02①		
		1NO-1NC	YW1B-A4E11①		

Note: Specify a button color code in place of ① in the Type No.


Dimensions




• Flush



• Mushroom



• Extended



All dimensions in mm.